















FRIGIDAIRE MONOTUBE STYLE SURFACE ELEMENTS	SURFACE ELEMENTS	WESTINGHOUSE STYLE
<p>5306590804 6" 2 Wire 5306590805 8" 2 Wire 5306590807 6" 3 Wire 5306590808 8" 3 Wire 5306591863 6" Speed Heat</p> 	 <p>5300161845 6" Plug In, 4 Turn. Uses 530013470 Block 5300162753 8" Plug In, 5 Turn.</p>	 <p>5300123745 6" Wire In c/w Block. 5300123749 8" Wire In c/w Block.</p>
 <p>5300207933 6" Element, C/W Ceramic Block. 5300207953 8" Element, C/W Ceramic Block. (5300211563)</p>	 <p>355T152S01 6" Wire In. 355T153S01 8" Wire In.</p>	 <p>5303207049 Burner Knob. Silver Trim.</p>
SURFACE ELEMENTS	FRIGIDAIRE PLUG IN STYLE	
 <p>5303015715 8" 4 Turn Element.</p>  <p>5303015716 6" 3 Turn Element.</p>	 <p>5303012223 8" 5 Turn Element.</p>  <p>5301314951 6" 4 Turn Element.</p>	 <p>5303207041 Thermostat Knob. 1/4" Flat Up.</p> <p>5303207664 Thermostat Knob. 3/8" Flat Down.</p>
BURNER BLOCKS	FRIGIDAIRE PLUG IN STYLE	
 <p>5303912666 Screw Mounts Vertically.</p>	 <p>5301167733 Screw Mounts Horizontally.</p>	 <p>5303935058 Universal Block Kit.</p>



5309957097
8" Switch, 10-11.5 Amps



5309957098
6" Switch, 5.2-6.6 Amps




5309957099
8" Switch, 8.9-11 Amps




5309957100
6" Switch, 5.2-6.6 Amps

Used on Frigidaire Ranges Built By GM. Includes Breakaway Shaft and Instructions.
5309957097 May be used to replace 6" "Speed Heat Switch".



5300600491 6"
5300600492 8"
Popular Westinghouse Switch.
Includes 3 Shafts & Multi
Mounts.



5303935086 CCW Rotation
5303935089 CW Rotation
Universal Switch Kit. 15 Amp, at 120/240V.



5309957156
6" Switch, 5.2-6.6 Amps.
Used on Frigidaire Ranges
Built By GM.
180 Degree Rotation.




5309957157
8" Switch, 8.9-11 Amps.
Used on Frigidaire Ranges
Built By GM. 180 Degree
Rotation.




5303051540
New 6" Push to Turn Switch
QE214309 6990006001.
5301313767
8" Push to Turn Switch.



5308010418
Popular Tappan 6"& 8"
Push to Turn Switch.
(699T014P04)



355T109S03
6" & 8" Infinite Switch.



5300162224
Popular Westinghouse
Combination Switch
Thermostat.
5300162222
Switch Thermostat.
5300162225
Switch Thermostat.




5303934039
Westinghouse Self Clean
Thermostat.
(QE216026).



Common GM Style
Thermostats
5306564063 "A"
Ranco 1" Shaft.
5307522594 "A"
Ranco 3/4" Shaft.
5309957110 "B"
Frigidaire Robertshaw.

Part numbers and illustrations intended solely for identification. Items offered for sale not represented to be manufactured by the company that built the item.



5301309973
Thermostat, 30 amp
2 Wire. Possible Reference#
1305733 1309973
1305743 1310650
1305744 242799
1305745 834601
1305748 G1-2667.



5303208040
Tappan Thermostat, 30 amp
2 Wire. Possible Reference #
720T031P01, G1-5885.




5300636387
Frigidaire Thermostat.



5308005306
Kelvinator Thermostat, 30 amp
2 Wire. Possible Reference#
1322360
1322361
3051542
6721G0018
EA5-344
WB21X5239.




5303208019
4 Position Selector Switch.
(ARS4167-146, 697T030P03).



5303208018
5 Position Selector Switch.
(ARS5167-38, 697T029P06).



5301311584
Bake Broil Selector Switch.
Rocker Switch.




5308003253
Infinite Bake & Broil Switch.
(K1311985).




5301305148
Infinite Bake & Broil Switch.
(K1305148).

to ensure correct part please provide model # whenever possible



5308016480
Infinite Bake & Broil Switch.
White Body 13.0-14.4A
(697G001P01,KS873416).



5301301584
Bake & Broil Switch.
KS873413.

























5300632171
Oven Relay.

FRIGIDAIRE

BAKE/BROIL ELEMENTS & IGNITORS

RANGE

FRIGIDAIRE

ELEMENTS				
 5303051519 Bake Element. 19 1/4 x 15"	 5308003347 Bake Element. 15 1/2 x 19"	 5309950887 Bake Element. 12 7/8 x 19"	 5309950885 Bake Element. 18 1/4" x 14 1/4"	 5309950886 Bake Element.
 5300207517 Bake Element. 18 x 15 1/4"	 5300210521 Bake Element. Uses 5300134268 Black.	 5300210911 Bake Element. Uses 5300134266 Block.	 5300210972 Bake Element.	 5300210981 Bake Element.
 5309950888 Bake Element.	 5300210961 Bake Element.	 5300210922 Broil Element.	 5303051516 Broil Element. 13 x 16"	 5300207513 Bake Element.
IGNITORS				
NUMBERS ON IGNITORS CAN PROVIDE A CROSS REFERENCE				
 5303935066 Universal Ignitor. 3.72" Body Length, 18" Wire Length.	 5304401265 Round Ignitor fits other brands.	 5303935068 Universal Ignitor. 7.53" Length, 12" Wire Length.	 5303912586 Carborundum Ignitor, Replaces Round Style, 3.72" Length, 4" Wire Leads.	 5303200508 Universal Ignitor. 6.28" Length, 11.5" Wire Length.
 5303935067 Universal Ignitor 5.53" Length, 14" Wire Length.	 316T023P05 Tappan Ignitor. 1 7/8" Length, 3" Wire Length.			

Part numbers and illustrations intended solely for identification. Items offered for sale not represented to be manufactured by the company that built the item.

WEST TUCSON
520.293.8888


















LAS VEGAS
702.382.6532
















RENO
775.348.9090

SALT LAKE CITY
801.975.1333

SAN ANTONIO
210.223.2675

SAN ANTONIO
210.525.0636

 <p>5303912679 Oven Safety Valve. 7/16" Tubing.</p>	<p>NUMBERS ON VALVE CAN PROVIDE A CROSS REFERENCE</p>		 <p>Looking For a part? Call Us</p>
 <p>5303208499 Dual Safety Valve Used with Flat Ignitor.</p>	 <p>5308009419 Oven Safety Valve. 3/8" Tubing.</p>	 <p>5303208063 Oven Safety Valve for Round Ignitor.</p>	 <p>5301315026 Gas Oven Temperature Control.</p>
 <p>5303011805 Bulb Clips.</p>	 <p>5308008001 Push to Turn Burner Valve. Vertical.</p>	 <p>5303131057 Push to Turn Burner Valve. Horizontal.</p>	 <p>5303912680 Push to Turn Burner Valve. Horizontal.</p>
 <p>5303288190 Surface Burner Valve with 1" Shaft.</p>	 <p>316035200 Top Ignitor Switch.</p>	 <p>5303131079 Rear 5303131080 Front Top Burner.</p>	 <p>5303204154 Rear 5303204155 Front Top Burner.</p>
 <p>5303912606 Spark Module, 4 wire.</p>	 <p>5303011567 New Style Snap In Top Burner.</p>	 <p>5300007473 Burner Cap.</p>	<p>WE ARE APPLIANCE PARTS Specialists</p>

<p>DEEP DRIP BOWLS WESTINGHOUSE</p>  <p>5300147221 6" Bowl. 5300147223 8" Bowl. Ridge Depth of Ring 3/4".</p>		<p>CHROME BOWLS WESTINGHOUSE</p>  <p>5300131961 6" Bowl. Ring 5300131986 5300131694 8" Bowl. Ring 5300131987</p>		
<p>HEAVY BOWLS TAPPAN & KELVINATOR</p>  <p>5303280336 6" Bowl. 5303013588 8" Bowl. Ridge Depth of Ring 3/8".</p>		<p>5308003113 6". 53080003114 8". 318138500 6". 3181385018".</p>  <p>5300203632 6" Bowl. 5300203632 8" Bowl.</p>		
<p>3 PIECE PANS GM FRIGIDAIRE</p>  <p>5307537053 6" Aluminum Bowl. 5306565456 6" Procelain Bowl. 5307537054 8" Aluminum Bowl. 5306565457 8" Procelain Bowl.</p>		 <p>5303295335 6" Porcelain Pan & Chr. Ring 5303302434 8" Porcelain Pan & Chr. Ring</p>	 <p>5307529769 6" Tripod Support. 5307529770 8" Tripod Support.</p>	
<p>RINGS</p>  <p>5300131986 6" Ring, Matches with bowl 5300131961.</p>		 <p>5300131987 8" Ring, Matches with bowl 5300131964.</p>	 <p>5303291616 (5307525673) 6" Chrome Ring with Clips.</p>	 <p>5303291617 (5307525674) 8" Chrome Ring with Clips.</p>
<p>GAS PANS & GRATES</p> <p>8 1/2"</p>  <p>5303207018 Old Style Pan (Teardrop).</p>		<p>8 1/4"</p>  <p>5303131115 New Style Pan.</p>	 <p>5303009309 Grate. Inner Dia. 7 1/2".</p>	 <p>316055800 Grate.</p>






















Part numbers and illustrations intended solely for identification. Items offered for sale not represented to be manufactured by the company that built the item.

RANGE

FRIGIDAIRE

RANGE & MICROWAVE PARTS

FRIGIDAIRE

 <p>08010449 Oven Door Gasket. 14"W x13"H</p>	 <p>5303051069 Oven Door Gasket. 14"W x13"H</p>	 <p>5308003268 Oven Door Gasket. 24"W x12"H</p>	 <p>5308008022 Oven Door Gasket. 21"W x13"H</p>
 <p>5303201944 Black Plastic Handle. Side Mount.</p>	 <p>5301167752 Broil Stop Roller Kit For Oven Door Hinge. (fits other brands)</p>	 <p>316007001 Oven Door Hinge. Fits Either Side, Illustrated. 316007002 Oven Door Hinge.</p>	 <p>5303912599 Oven Door Springs.</p>
 <p>316607001 Oven Door Spring.</p>	 <p>5303205939 Left Door Hinge. 5303205940 Right Door Hinge</p>	 <p>5303011698 14 1/4" x 15 1/4" 5303091188 10 3/4" x 15 1/4" Rectangular Glass Tray.</p>	 <p>5308037674 Turntable with Square Drive, 12 1/2".</p>
 <p>5303207556 (5308010514) Microwave Glass Tray. Fits 1 Cubic Foot with Propeller Shaped Stirrer, Belt Drive Models. 5303305512 (5308010514) Microwave Glass Tray. Fits 1.2 Cubic Foot with Delta Shaped Stirrer, Direct Drive Models.</p>	 <p>5303303047 Turntable Drive. 7/8" Square & 1/4" Drive. Extended Shaft.</p>  <p>5303922044 Turntable Drive. 7/8" Square & 1/4" Drive.</p>	 <p>53039340402 Door Handle.</p>	 <p>5308011737 Door Handle. 5303206956</p>
 <p>A B</p> <p>5303091303 Diode. 1/4" Spade = A 3/16" Spade = B</p>	 <p>5303011495 Microwave Belt White Rubber.</p>	 <p>5303131298 5 Amp Glass Fuse.</p>	 <p>5303305343 (5303091280) Thermal Fuse 105 C.</p>

OVEN DOOR GASKETS



5303051704
Oven Door Gasket.
29" x 17".



5303131601
Oven Door Seal, 60".



5303202011
Oven Door Seal
18" x 12".



5303934092
Oven Door Seal
19-1/2" x 12-1/2"

BURNERS



316039002
Top Burner Front.



316039003
Top Burner Rear.



316057100
Top Burner.



5303935025
Top Burner.



5303208105
Flame Switch, 26" Capillary.



5303210233
Oven Door Hinge - Left.



5308003183
Oven Door Hinge - Left.




not exactly as illustrated.

5308003198
Oven Rack, 16-1/2" x 23"



5303131297
Fuse, 5A, Glass.



5300007473
Burner Cap.



316010901
Burner Cap.



8010568
5-1/2" unstretched oven door
spring.



27994
Pilot Light.



5301314211
Oven Light Switch. Heat
Resistant.



3051163
Rear Drawer Glide



not exactly as illustrated.

5303284616
5300009126
Bulb Clips for oven thermostat
bulbs.

Part numbers and illustrations intended solely for identification. Items offered for sale not represented to be manufactured by the company that built the item.

RANGE

FRIGIDAIRE

RANGE & MICROWAVE PARTS

FRIGIDAIRE

		RANGE KNOBS	
			
316101103 Clock Timer.	5303310267 Element Cleaner.	5303303405 Gas Burner, "D" Shaft.	5303303408 Gas Oven, "D" Shaft.
			
3051187 EL. Oven, "D" 1/4" Flat.	3131695 Gas Burner, "D" Shaft.	3201697 EL. Selector, "D" Shaft.	3205115 Gas Oven, "D" Shaft.
			
358T174P27 EL. Range, "D" Shaft.	5303051028 EL Surface, Clip Down.	5303051405 EL. Surface, Flat Up.	5303091393 EL. Surface, Flat Down.
			
5303131953 EL. Oven, "D" 1/4", Flat Up.	5303207036 EL Surface, "D" 1/4", Flat Up.	5303207042 Gas Burner, "D" 3/8", Flat Dn.	5303207043 Gas Burner, "D" 3/8", Flat Dn.
			
5303207048 EL. Oven, "D" 3/8", Flat Up.	5303207663 EL Ring, "D" Shaft.	5303209616 Gas Burner, 1".	5303302476 Gas Burner, O/H/L.
			
5303935142 Gas Ring, "D" 7/8".	5305156302 Surface, "D" Shaft.	5307532411 EL. Surface, Vertical Off.	5308950179 EL. Surface, Vertical Off.

*Note: EL = Electric D = Description of switch shaft shape